


TF Card MP3 Player Board

Pins assignment:



| Pin | Function |
|-----|-----------------------------|
| 13 | Busy (Output LOW when busy) |
| 15 | RX (TTL) |
| 16 | TX (TTL) |
| 17 | Audio out R |
| 18 | Audio out L |
| 19 | GND |
| 20 | DC 12V |

Control command set:

| Command (hex) | Function |
|---------------|-----------------------------------|
| 000 | Random play |
| 001-199 | Play specified MP3 file (000-199) |
| E8 | Volume + |
| E9 | Volume - |
| EA | Play/Pause |
| EB | Hold |
| EC | Resume |
| EF | Stop |

Specification:

| | |
|---------------------|--|
| Format: | MP3 only |
| File naming: | 001.mp3, 002.mp3...199.mp3 (Total 199 songs) |
| Interface: | Rx, Tx @TTL level |
| Baud Rate: | 4800,N,8,1 |
| SD card: | 32M or up |
| Power input: | DC 12V |

MDFLY

www.mdply.com