




UB4-08	Description	Page No
	RF to Baseband Connections	A1-1
	Baseband Block Diagram	A1-2
	Audio RFI	A1-3
	CPU	A1-4
	Power Supply and Charging	A1-5
	RF Block	A1-6
	User Interface	A1-7
	Component Layout	A1-8


RF to Baseband Connections


RF BB

















Component Layout

