





Description	Page No
UB4-10	
RF to Baseband Connections	A2-1
Baseband Block Diagram	A2-2
Audio RFI	A2-3
CPU	A2-4
Power Supply and Charging	A2-5
RF Block	A2-6
User Interface	A2-7
Component Layout	A2-8

Rf to Baseband Connections









PRODUCT DEPENDENT MEMORY COMPONENTS




Power Supply and Charging



* SEE SCHEMATIC SHEET8





ONLY FOR PCB VERSION 10 AND LATER

N502	Part.no	R312	R311
RFMD	4350277	ADD	ADD
Philips	4350269	DEL	ADD
Hitachi	4350259	ADD	DEL

